




P8-HDBT-L-SP4

# QUICK SETUP GUIDE



- A Power** Use the supplied mains power cable and connect to the device. Do not use any other power cables with this product.
- B Ethernet** Connect to system to your router or network switch. This must be done in order to use the remote monitoring portal.
- C HDMI Input** Connect a HDMI source device (i.e Blu-Ray player) to this port using a HDMI cable (not supplied).
- D Infrared Output** Connect the supplied IR emitter to this port to control source device
- E Stereo Output** 3.5mm audio breakout
- F HDBaseT Outputs** Connect sink devices (i.e TV) to the outputs via CAT cable. Complete the connection by attaching a neo:Lite Reciever (sold separately) to the CAT cable and link to sink device via HDMI cable (not supplied).

# INITIAL SETUP

## 1 CONNECT INPUT DEVICE

Using the 'HDMI Input' port, connect to the source device (i.e Blu-Ray player) using a HDMI cable (not supplied).

## 2 CONNECT ETHERNET

Connect a standard Ethernet cable to the 'Ethernet' port from your router or network switch, cross over cables are not supported.

## 3 CONNECT OUTPUT DEVICES

Sink devices are connected via CAT cable from the Output port to a neo:Lite receiver (supplied seperately). Complete the connection from the receiver to the Sink device (i.e. your TV) via a HDMI cable.

## 4 CONNECT INFRARED

Using the supplied IR emitter, connect to the IR out port on the splitter and place the bud over the IR window on the source device.

## 5 CONNECT POWER

Use the supplied power supply, connect to the DC 48V port. Ensure the source and sink devices are powered on before powering on the splitter.

## 6 REMOTE MONITORING

This device can also be registered on our Remote Monitoring Portal via **[monitoring.pulse-eight.com](https://monitoring.pulse-eight.com)**

### COPYRIGHT NOTICE

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means (electronic, mechanical, magnetic, optical, chemical, manual, or otherwise) without express written permission and consent from Pulse-Eight Limited.

© Copyright 2019 Pulse-Eight Limited. All Rights Reserved.  
Version 1.0 - August 2019

### **Pulse-Eight Limited**

8-12 Alder Hills . Poole . Dorset . BH12 4AL . UK  
sales@pulse-eight.com | +44 (0)1202 413610  
www.pulse-eight.com