

SPECIFICATIONS			
Leviton Security & Automation Controllers	OmniPro II	Omni ITe	Omni LTe
Leviton Security & Automation Lighting/Rooms	31	8	4
Lighting Scenes	128	64	32
Lighting Addresses	256	64	32
Zones	16	16	16
Zone Expansion Total	176	48	32
2 Wire Smoke Loops	4	4	4
4 Wire Smoke Loops	176	48	16
Thermostats	64	4	4
Consoles (Keypads)*	16	8	4
OmniTouch 7/OmniTouch Pro	16	16	16
12 Volt Triggers (w/ expansions)	8 (136)	8 (8)	8 (8)
Audio Control	Hi-Fi 2/Conn.Prtnrs	Hi-Fi, Hi-Fi 2	Hi-Fi, Hi-Fi 2
Audio Zones	16/36	8	8
Access Control Card Readers	16	4	4
Access Control Card/Keytag	99	16	16
Serial Ports	5	5	5
Serial Expansion Total	6	6	5
Ethernet Port	Yes	Yes	Yes
Flash Memory	Yes	Yes	Yes
User Codes	99	16	16
Programming Lines	1500	500	300
Vocabulary	550	550	550
Custom Vocabulary	Yes	No	No
Depluggable Terminal Strips	Yes	Yes	Yes
Format	Contact ID, 4/2,3/1	Contact ID, 4/2,3/1	Contact ID, 4/2,3/1
Transformer Required	24V (40VA)	24V (40VA)	24V (40VA)
Battery (Typical)	12V (7 Ah)	12V (7 Ah)	12V (7 Ah)
Aux Current Max	1A	1A	1A
Bell Current Max	1A	1A	1A
Aux Current (UL 24hr.)	250mA	250mA	250mA
Bell Current (UL 24hr.)	300mA	300mA	300mA
Total Expansion Boards (10A06-1)	2	2	0
Total Expansion Enclosures (17A00-X)	8	0	0
Total 64-Zone Wireless Receivers (45A00-1/42A00-2)	8**	1	1
110V/220V/240V	Yes	Yes	Yes
UL Listing	Res. Burg/Fire; Comm. Burg	Res. Burg/Fire; Comm. Burg	Res. Burglar/Fire
Warranty	3 years	2 years	2 years

* Systems must have one console to meet UL requirements.

** Wireless Receivers can support 64 Transmitters and can report to 16, 32, 48, or 64 zones, depending upon your setup. Each group of 16 zones counts as one expansion enclosure.