

# OWNER'S MANUAL

## SE1612 Sound Enclosure

### Specifications to mount a SE1612 Sound Enclosure

- The enclosure provides one hour fire break protection.
- The enclosure will reduce the sound travel between the wall into adjacent up to 10db.
- The enclosure will provide a template for the drywall cut-out leaving a perfect location for mounting the speakers.
- The air volume inside the enclosure is ideal for most 6 1/2" two-way in-wall speaker systems.
- The enclosure is lined with a sound deadening material to minimize resonance and packed with an insulation material to absorb sound from the speaker.

### Enclosure Assembly



The SE1612 comes ready to install: The unit includes a fitting to clamp the speaker wire firmly to aid in installation and fire protection.

The enclosure has eight mounting holes to accommodate variations in stud spacing. When the drywall is hung there is also a flange for the drywall installer to cut around. The finished installation leaves a perfect location for mounting the speaker (See Figure #1).

### Enclosure Installation

Choose a location where you want to mount the speaker. Refer to the installation manual that comes with the speaker for optimum placement.

1. Place the enclosure between the studs, use a level to line up the enclosure, then mount it using four drywall screws (See figure #2).
2. Feed the speaker wire through the fitting leaving approximately 18" of wire in the enclosure. Then tighten the clamp with a screwdriver. DO NOT OVER TIGHTEN THE CLAMP OR IT MAY DAMAGE THE SPEAKER WIRES.
3. After the drywall has been hung, attach the speaker wire to the speaker and install the speaker according to the speaker's instructions.



SpeakerCraft offers a variety of accessories to make your installation of this and other SpeakerCraft products easy, economical, and professional. Contact your authorized SpeakerCraft Dealer for more information.

Should you have any questions regarding this, or any other SpeakerCraft product, please call our toll-free service hotline at 1-800-448-0976. We are available to assist you every weekday, except holidays, between the hours of 7:00 a.m. and 5:00 p.m. PST.