





# CONNECTION DIAGRAM



## IR CONTROL DIAGRAM



### Control System Direct

When direct wiring from a emitter or IR output on a control system.  
Example: Control System IR out --> IR in on the extender.

3.5MM CABLE  
(AS SHOWN ABOVE, AVAILABLE  
THROUGH AVPROCONNECT)



BACK

HDBASET CAT 5/6/7

CONTROL PROCESSOR

DIRECT USING THIS CABLE OR IR RE-  
CEIVER EYE.





FRONT



BACK

