




DI-021-SY691-05A_{AR2253}
(69I00-1)

WIRELESS 4-BUTTON KEYPAD

Cat. No. 69A00-1

Installation Instructions

The 69A00-1 4-Button Keypad is used to send up to 10 different wireless signals to the Leviton 45A00-1 Wireless Receiver to activate automation programs in the Leviton controller. Each button, or combination of buttons, can activate lighting, arm and disarm the security system, operate a garage door, set off a panic alarm, and many other functions.



WARNINGS AND CAUTIONS

- Read and understand all instructions. Follow all warnings and instructions marked on the product.
- Do not use this product near water - e.g., near a tub, wash basin, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
- Never push objects of any kind into this product through openings, as they may touch dangerous voltages.
- Never install communications wiring or components during a lightning storm.
- Never install communications components in wet locations unless the components are designed specifically for use in wet locations.
- Never touch uninsulated wires or terminals unless the wiring has been disconnected at the network interface.
- Use caution when installing or modifying communications wiring or components.
- **SAVE THESE INSTRUCTIONS.**

OPERATION

When you press a button on the Keypad, a transmission will be sent after a 3/10 second delay. If desired, you can program the buttons to have a variety of delays to help avoid accidental transmission. When the signal is transmitted, the LED will light for conformation that the transmission was sent.

NOTE: Button 4 is factory programmed to have a 2 second delay. You must press and hold Button 4 for 2 seconds before it will transmit.

You can also virtually eliminate false panic alarms by configuring the panic alarm to only activate when two buttons are pressed simultaneously. This configuration is perfect for Police or Duress panic alarms. It helps reduce false alarms by insuring a signal is sent only if two buttons are pressed simultaneously.

Enrolling each of the 4 Buttons on the 69A00-1:

To enroll the 69A00-1, put the 45A00-1 Wireless Receiver in to Setup mode, advance to an unused address location, and then press one of the buttons on the Keypad. Advance to another unused address location, and then press the next button for two zones. Advance to another unused address location and press the next button for three zones. Advance to another unused address location and press the final button for four zones. Refer to the Installation Instructions for the 45A00-1 Wireless Receiver for additional information.

Using the 4 Additional Zone Inputs:

A combination of button presses can be used to activate 6 additional zones. To activate these zones, the combination of buttons must be pressed simultaneously.

To enroll the 6 additional zones on the 69A00-1, follow the procedure as stated above, but use a combination of buttons. Refer to the Installation Instructions for the 45A00-1 Wireless Receiver for additional information.

PROGRAMMING FEATURES

The 69A00-1 can be programmed to change some operating parameters to provide maximum flexibility.

To Enter Programming:

- 1) Press and HOLD all four buttons simultaneously until the LED begins to flash (approximately 2 seconds).
 - 2) Press Button 1 for a 2-second delay¹ on Button 4 (default) or press Button 2 to set the delay on Button 4 to the programmed delay on all other buttons.
- Once you have pressed Button 1 or Button 2, the LED will begin to flash faster.
- 3) With the LED flashing, press Button 1 for instant transmission on all buttons², press Button 2 for a 3/10 of a second delay¹ (default) on all buttons², press Button 3 for a 1 second delay¹ on all buttons², or press Button 4 for a 2 second delay¹ on all buttons².

The LED will stop flashing to indicate that the unit has exited programming.

¹ The delay requires you to hold the button(s) for that amount of time before the signal is sent. If you program a 3/10 of a second delay, then the signal will not be sent unless you hold the button(s) for 3/10 of a second (to reduce inadvertent presses).

² "on all buttons" includes the combination of button presses that are used to activate the 6 additional zones; however, does not include Button 4 when it is configured for a 2 second delay.

ADDITIONAL FEATURES:

- Slim design: Slim 0.3" inch atop wall or mounting location for an elegant built-in look (4.5"H x 2.75"W x 0.3"D).
- Ultra Powerful Transmitter: The 69A00-1 out performs the competition.
- 10 Zones: The 69A00-1 is the ultimate wireless Keypad for today's homeowner. You can control up to ten automation features including lighting, arming and disarming the security system, panic alarms, garage doors, and much more.
- LED indication: The red LED on the front visually confirms that the signal has been sent.
- Tactile feedback: When any button on the 69A00-1 wireless Keypad is pressed a 'click' can be felt. This tactile feedback coupled with the visual LED gives absolute confirmation that the signal was sent.
- Mounting hardware: The 69A00-1 can be screwed onto the mounting location or can simply be stuck to the mounting location using the supplied double-stick mounting tape.
- Long Life Lithium Batteries: The 69A00-1 4-Button Keypad is equipped with CR2032 long life lithium batteries. The average life is 7-10 years under normal conditions before it reports a low battery condition.

FOR CANADA ONLY

For warranty information and/or product returns, residents of Canada should contact Leviton in writing at **Leviton Manufacturing of Canada Ltd to the attention of the Quality Assurance Department, 165 Hymus Blvd, Pointe-Claire (Quebec), Canada H9R 1E9** or by telephone at **1 800 405-5320**.

FCC COMPLIANCE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

LEVITON LIMITED WARRANTY

Leviton warrants to the original consumer purchaser and not for the benefit of anyone else that products manufactured by Leviton under the Leviton brand name ("Product") will be free from defects in material and workmanship for the time periods indicated below, whichever is shorter: • **OmniPro II and Lumina Pro:** three (3) years from installation or 42 months from manufacture date. • **OmniLT, Omni IIe, and Lumina:** two (2) years from installation or 30 months from manufacture date. • **Thermostats, Accessories:** two (2) years from installation or 30 months from manufacture date. • **Batteries:** Rechargeable batteries in products are warranted for ninety (90) days from date of purchase. **Note:** Primary (non-rechargeable) batteries shipped in products are not warranted. **Products with Windows® Operating Systems:** During the warranty period, Leviton will restore corrupted operating systems to factory default at no charge, provided that the product has been used as originally intended. Installation of non-Leviton software or modification of the operating system voids this warranty. Leviton's obligation under this Limited Warranty is limited to the repair or replacement, at Leviton's option, of Product that fails due to defect in material or workmanship. Leviton reserves the right to replace product under this Limited Warranty with new or remanufactured product. **Leviton will not be responsible for labor costs of removal or reinstallation of Product.** The repaired or replaced product is then warranted under the terms of this Limited Warranty for the remainder of the Limited Warranty time period or ninety (90) days, whichever is longer. This Limited Warranty does not cover PC-based software products. **Leviton is not responsible for conditions or applications beyond Leviton's control. Leviton is not responsible for issues related to improper installation, including failure to follow written Installation and operation instructions, normal wear and tear, catastrophe, fault or negligence of the user or other problems external to the Product.** To view complete warranty and instructions for returning product, please visit us at www.leviton.com.

Use herein of third party trademarks, service marks, trade names, brand names and/or product names are for informational purposes only, are/may be the trademarks of their respective owners; such use is not meant to imply affiliation, sponsorship, or endorsement.